


# FRAME ASSEMBLY

Part No.	Part Name
1-A	-UPRIGHT-R.H.
1-B	-BED
1-C	-CROWN
1-D	-UPRIGHT-L.H.
23	-SLIDE-(OR PLUNGER)
199	-MAIN TIE ROD
200	-MAIN TIE ROD NUT
354	-SIDE SHEAR
1001	-MAIN MOTOR PLATE

FIG. 1.



## SHIPPING

Your Bliss Straight Side press is shipped as completely assembled as practical by either of two methods.

- Press completely assembled except for gears, gear guards, flywheel and motor.
- The larger sizes will have the frame disassembled or "knocked down" with individual parts skidded to facilitate handling under normal shipping regulations.

In either method all machined surfaces are coated with an anti-rust slushing compound which must be removed before the press is put in operation. Kerosene or any suitable solvent may be used for cleaning. Oilite bearings used on presses with rolling key clutches are covered with waterproof paper for shipment and are not coated with anti-rust slushing compound. *Do not use Kerosene on the interior of these bearings.*

## FRAME CONSTRUCTION

Bliss Straight Side presses are of four piece frame construction which consists of a bed, two uprights and a crown held together by four steel tie rods which are shrunk in at assembly to take the load of the press.

The extra heavy uprights are keyed to the bed and crown to withstand any lateral loads which may occur when an eccentric load is produced on the slide. The uprights also provide a mounting surface for the wear strips and adjustable gibs which in turn guide the slide in its vertical motion.

## FRAME ERECTION

Erecting the frame is only necessary when the press is shipped to you "knocked down." This erection may be done by either of two methods, depending on the amount of head room available.

**Vertical Method:** This is the preferred method but it requires more head-room than the horizontal method.

- Place the bed in position on the foundation. The bed should be set level front to back and right to left with provision for about 1" of grouting.

# CRANKSHAFT CROWN AND CAP ASSEMBLY




Fig. 2.

Part No.	Part Name		Part Name
1-C	—CROWN	2-F	—CRANKSHAFT MAIN BEARING CAP BUSHING DOWEL
1-C-1	—CROWN AND UPRIGHT KEY	5	—CRANKSHAFT
1-C-2	—CROWN AND UPRIGHT KEY SCREW	128	—CRANKSHAFT END BEARING STUD
2	—CRANKSHAFT MAIN BEARING CAP	129	—CRANKSHAFT END BEARING STUD NUT
2-A	—CRANKSHAFT MAIN BEARING CAP BUSHING	129-A	—CRANKSHAFT END BEARING STUD LOCK NUT

**NOTE** — When no pit is used the bed should be first placed on blocks with sufficient clearance for the tie rod nuts to slide underneath.

- 2—Place the tie rod nuts in position under the bed.
- 3—Put the tie rods inside of the upright.
- 4—Place the uprights and tie rods in position on the bed, lowering the tie rods on the nuts.
- 5—Put the lower nuts on the tie rods.
- 6—Place the crown in position.
- 7—Raise the tie rods and put on the top nuts and screw tight taking up all slack.

**Horizontal Position:** When head room is limited.

- 1—Lay the bed on its back and level up.
- 2—Place the uprights in position.
- 3—Place the crown in position.
- 4—Put the nuts on the bottom of tie rods.
- 5—Insert the tie rods in the frame.
- 6—Put on top nuts and screw tight, taking up all slack.
- 7—Raise press and mount on foundation leveling front to back and right to left leaving space for about 1" of grouting.

## SHRINKING OR PRELOADING THE TIE RODS

The tie rods should be heated until they have expanded sufficiently to be able to take up the tie rod nuts an additional amount equal to .0083 inch per foot of tie rod length, measured between the nuts.

**Method of Heating Tie Rods:** Near the bottom of each upright there is an opening for heating the tie rods. Protect the uprights with asbestos  $\frac{1}{4}$ " thick, then apply heat to the tie rods by an acetylene torch, or other means, capable of spreading a generous and equal flame around the full circumference, using an up and down movement to prevent burning the tie rod.

**NOTE**—Care should be exercised in not giving the rods too much shrink, as this would unduly strain the frame.

If it becomes necessary to dismantle a press of Bliss four-piece tie rod construction, it is advisable to preheat all tie rods and allow an interval of fifteen (15) minutes before applying second heat to remove the nuts.

## SLIDE ADJUSTMENT LIMIT SWITCHES

Presses arranged with power elevating attachments are provided with two slide adjustment overtravel limit switches that are wired through their normally closed contacts, between the adjusting motor starter and its "RAISE" or ("UP") and "LOWER" or ("DOWN") buttons. It is important that these limit switches be properly set to eliminate jamming of the connecting screw and the connection at the up position of the adjustment and to prevent the screw from coming out of the connection at the down position.

The limit switches and their actuating arms are properly set before shipment but either or both may become damaged or misaligned in shipment. Before starting the slide adjusting motor the following checkups should be made.

1. Make sure that both limit switch arms are securely fastened to the limit switch shafts.
2. Check to see that limit switch rollers can be actuated by the limit switch trip bracket.
3. Loosen the locking screw (18-C) three or four revolutions to spread the clamping plugs (18-A) and (18-B). Do not loosen the anchor screws (19-A). BE SURE THAT THE CLAMPING PLUGS ARE RE-TIGHTENED BEFORE STARTING THE PRESS.
4. Set selector switch to "Slide Adjusting" position. Start the slide adjusting motor by pressing either the "RAISE" or "LOWER" button (dependent on the position of the slide) and then actuate

the proper limit switch arm by hand to see that it actually interrupts the circuit to the starter.

The following procedure should be used to set the limit switches. The limit switches require a travel of 10 degrees, or approximately  $\frac{1}{4}$ " (measured at the center of the roller) before the switch breaks the circuit after the dog has contacted the roller. This must be allowed for, in setting the switches.


A. Set selector switch to "Press Operating" position.

B. Use "Inch" button to run slide to its bottom stroke position (crank pin down).

C. Set selector switch to "Slide Adjusting" position.

D. Adjust the slide to the minimum die height by carefully inching the slide down by pressing the "LOWER" or (DOWN) button. Set arm of limit switch to break at this point, allowing for 10 degrees travel as described above.


E. After the low position limit switch has been set, then the slide should be carefully inched upward by use of the "RAISE" or "UP" button. When the maximum die height is reached then the limit switch arm should be set accordingly, allowing for the 10 degrees travel as described above.



See Page 9 for Parts Identification


FIG. 3.

# PRESS CONNECTIONS AND ADJUSTMENT ASSEMBLIES



TYPE K & L CONNECTION

FIG. 4.




TYPE N CONNECTION

FIG. 5.

- |       |   |        |  |
|-------|---|--------|--|
| 14    | Connection Cap  | 219    | Connection Screw Gear, Spur                              |
| 14-A  | Connection Cap Bushing                                | 241    | Adjusting 1st Driven Gear                                |
| 15    | Connection Cap Stud                                   | 246    | Adjusting 1st Drive Pinion                               |
| 16    | Connection  | 247    | Adjusting 1st Drive Pinion Key                           |
| 18-A  | Connection Screw Clamping Plug (head end)             | 248    | Adjusting Main Driveshaft                                |
| 18-B  | Connection Screw Clamping Plug (nut end)              | 252    | Adjusting Motor Driven Pulley                            |
| 18-C  | Connection Screw Clamping Plug Screw                  | 381    | Connection Screw Gear, Bevel                             |
| 19-A  | Connection Screw Clamping Plug Anchor Screw           | 382    | Connection Screw Gear Pinion, Bevel                      |
| 19-D  | Connection Screw Clamping Plug Dummy Screw            | 607    | Adjusting 3rd Shaft                                      |
| 19-E  | Connection Screw Clamping Plug Spreader               | 608    | Adjusting 4th Gear Bushing, Pinion End                   |
| 20    | Connection Screw                                      | 609    | Adjusting 4th Gear Bushing, Gear End                     |
| 20-B  | Connection Screw Gear Key                             | 610    | Adjusting 4th Gear                                       |
| 20-C  | Connection Screw Adjusting Collar                     | 611    | Adjusting 3rd Gear                                       |
| 20-D  | Connection Screw Adjusting Collar Key                 | 612    | Adjusting Gear Case Bushing, 1st Driven Gear Shaft       |
| 21    | Connection Screw Ball Box Cap                         | 613    | Adjusting Gear Case Bushing, 1st Driven Gear Shaft       |
| 21-A  | Connection Screw Ball Box                             | 614    | Adjusting Gear Case Sleeve, 1st Driven Gear Shaft        |
| 23    | Slide   | 615    | Adjusting 1st Driven Gear Key                            |
| 66    | Oil Cup   | 616    | Adjusting Gear Case Bushing, Main Driveshaft, Pinion End |
| 130   | Connection Wrist Pin                                  | 617    | Adjusting Gear Case Bushing, Main Driveshaft, Pulley End |
| 142   | Connection Wrist                                      | 618    | Adjusting Gear Case Sleeve, Main Driveshaft              |
| 191   | Connection Screw and Wrist Retaining Bushing          | 619    | Adjusting Gear Case                                      |
| 192   | Connection Screw and Wrist Retaining Bushing Stud     | 620    | Adjusting Gear Case Anchor Key                           |
| 193   | Connection Screw and Wrist Retaining Bushing Stud Nut | 621    | Adjusting Gear Case Stud                                 |
| 201   | Connection Cap Stud Nut                               | 622    | Adjusting Gear Case Stud Nut                             |
| 206   | Elevating Motor Plate                                 | 623    | Adjusting Gear Case Sleeve Set Screw                     |
| 215   | Elevating Motor Plate Adjusting Screw                 | 993    | Adjusting 1st Driven Shaft                               |
| 215-A | Elevating Motor Plate Adjusting Screw Nut             | 997    | Adjusting Motor Plate Pivot Shaft                        |
| 215-B | Elevating Motor Plate Adjusting Screw End             | 998    | Adjusting Motor Plate Lug                                |
|       |   | 999    | Adjusting Motor Sheave                                   |
|       |   | 1004-D | Adjusting Motor  |
|       |   | 1004-E | Adjusting Motor Belt                                     |

# SIDE SHEAR ASSEMBLY




**FIG. 6.**

- 1-A. Upright, R. H.
- 1-B. Bed
- 1-C. Crown
- 1-D. Upright, L. H.
- 2. Crankshaft bearing cup
- 2-A. Crankshaft bearing cup bushing
- 5. Crankshaft
- 6. Crankshaft brake collar
- 7. Crankshaft brake collar key
- 8. Crankshaft brake band complete with lining
- 9. Crankshaft brake band attaching stud

- 10. Crankshaft brake band attaching stud nut
- 23. Slide (or plunger)
- 32. Gib, front, L. H.
- 33. Gib, front, R. H.
- 34. Gib screw (or stud)
- 35. Gib adjusting set screw
- 36. Gib adjusting set screw nut
- 37. Bolster plate
- 38. Bolster plate bolt
- 39. Bolster plate bolt washer
- 40. Bolster plate bolt nut
- 76. Balance wheel (or flywheel)
- 104. Gib stud nut
- 128. Crankshaft end bearing stud
- 129. Crankshaft end bearing stud nut
- 199. Tierod
- 200. Tierod nut
- 340. Connection screw clamping plug, R. H.
- 341. Connection screw clamping plug, L. H.
- 342. Connection screw clamping plug screw
- 343. Connection screw clamping plug anchor screw
- 344. Connection screw
- 344-A. Connection
- 344-B. Connection cap
- 344-C. Connection cap stud
- 344-D. Connection cap stud nut
- 344-E. Connection main bushing
- 345. Connection screw adjusting nut
- 346. Connection screw and wrist retaining bushing
- 347. Connection screw and wrist retaining bushing stud
- 349. Connection wrist
- 349-A. Connection wrist pin
- 350. Cutter holder, upper
- 351. Cutter, upper
- 352. Cutter, lower
- 353. Cutter holder, lower
- 354. Trimming slide
- 354-A. Main gib, outer
- 1000. Motor plate lug
- 1001. Motor plate
- 1002. Motor plate pivot shaft
- 1003. Motor plate pivot shaft cotter
- 1004. Motor sheave
- 1004-B. Belt, main
- 1004-C. Motor, main



# TYPE "K" CLUTCH SHAFT ASSEMBLY



Type "K" Clutch Shaft Assembly (Double Geared)

Part No.	Part Name
4	—CLUTCH WHEEL—OR FLYWHEEL
11	—BRAKE FRICTION DISC PIN
20	—BRAKE FRICTION DISC PIN SCREW
21	—CLUTCH FRICTION DISC PIN SCREW
30	—CLUTCH FRICTION DISC PIN
31-FW	—FLYWHEEL BEARING RETAINER SCREWS
32-FW	—FLYWHEEL BEARING SPACER—CENTER
33-FW	—FLYWHEEL BEARING
34-FW	—FLYWHEEL BEARING RETAINER
36-FW	—FLYWHEEL BEARING SPACER—INNER
37-FW	—FLYWHEEL BEARING SPACER—OUTER
38-FW	—FLYWHEEL BEARING RETAINER PACKING
42-FW	—FLYWHEEL BEARING ADJUSTING SHIMS
54	—SHAFT SPACER (To Clutch)
109-E	—DRIVE SHAFT BRACKET (Floating)
109-H	—DRIVE SHAFT BEARING SLEEVE (Fixed)
109-H	—DRIVE SHAFT BEARING SLEEVE (Floating)
109-J	—DRIVE SHAFT BEARING COLLAR (Fixed)
109-J	—DRIVE SHAFT BEARING COLLAR (Floating)
109-K	—DRIVE SHAFT BEARING (Fixed)
109-K	—DRIVE SHAFT BEARING (Floating)
109-L	—DRIVE SHAFT BEARING SPACER (Inner) (Floating)
109-M	—DRIVE SHAFT BEARING SPACER (Middle) (Fixed)
109-M	—DRIVE SHAFT BEARING SPACER (Middle) (Floating)
109-P	—DRIVE SHAFT BEARING END PLATE
109-R	—DRIVE SHAFT BEARING COLLAR PACKING (Fixed)
109-R	—DRIVE SHAFT BEARING COLLAR PACKING (Floating)
109-S	—DRIVE SHAFT BEARING COLLAR SHIM (Fixed)
109-S	—DRIVE SHAFT BEARING COLLAR SHIM (Floating)
109-T	—DRIVE SHAFT BEARING SLEEVE DOWEL
109-U	—DRIVE SHAFT BEARING SLEEVE DOWEL NUT
109-V	—DRIVE SHAFT BEARING SLEEVE SCREW
109-W	—DRIVE SHAFT BEARING SLEEVE SCREW NUT
117	—MAIN DRIVE SHAFT
117-B	—MAIN DRIVE SHAFT END BEARING SPACER
144	—MAIN DRIVE PINION
145	—MAIN DRIVE PINION KEY
165-A	—BRAKE BRACKET

# MAIN SHAFT ASSEMBLY




FIG. 9

## Main or First Intermediate Shaft Assembly — Twin End Drive

Part No.	Part Name
67	—MAIN OR 1ST INTER. SHAFT BRACKET—L.H.
67	—MAIN OR 1ST INTER. SHAFT BRACKET—R.H.
70	—MAIN OR 1ST INTER. SHAFT BRACKET CAP—L.H.
70	—MAIN OR 1ST INTER. SHAFT BRACKET CAP—R.H.
71	—MAIN OR 1ST INTER. SHAFT BRACKET CAP STUD
72	—MAIN OR 1ST INTER. SHAFT BRACKET CAP STUD NUT
73	—MAIN OR 1ST INTER. SHAFT
74	—MAIN OR 1ST INTER. PINION—L.H.
74	—MAIN OR 1ST INTER. PINION—R.H.
75	—MAIN OR 1ST INTER. PINION KEY—L.H.
75	—MAIN OR 1ST INTER. PINION KEY—R.H.
75-A	—MAIN OR 1ST INTER. SHAFT END COLLAR—L.H.
75-A	—MAIN OR 1ST INTER. SHAFT END COLLAR—R.H.
107	—MAIN DRIVE 1ST INTER. GEAR
107-B	—MAIN DRIVE 1ST INTER. GEAR SPACER
108	—MAIN DRIVE 1ST INTER. GEAR KEY
662	—MAIN OR 1ST INTER. PINION SPACER
665	—MAIN OR 1ST INTER. SHAFT BUSHING—L.H.
665	—MAIN OR 1ST INTER. SHAFT BUSHING—R.H.
665-A	—MAIN OR 1ST INTER. SHAFT BUSHING DOWEL