
STRAIGHT SIDE PRESSES

FORM A 13-M-1

NOTE: Machines with clutch on driveshaft, Serial No. 47200 and above - Once each year remove cover on clutch and lubricate flywheel bearings through fitting on the end of the driveshaft. Use Chevron SR-1 No. 2 grease, .

SINGLE GEARED TWIN END DRIVE

- 12, Clutch Hub Retainer Ring 13.
- 14. Brake Hub 15. Ring Gasket 16. Flywheel
- Inboard Flywheel Bearing 17.
- 18. Spacer
- Outboard Flywheel Bearing 19.
- 21. Clutch (See Separate Parts List)
- 22. L. H. Bearing Housing
- 23, Retainer Ring
- 24. Locating Bearing
- 25. Retainer Ring
- L. H. Intermediate Shaft 26.
- 27 Retainer Ring
- 28. Roller Bearing
- 29. Retainer Ring
- 30. L. H. Bearing Cartridge
- 31. L. H. Coupling (Consists of Two Pieces)
- 32. Middle Intermediate Shaft
- 33. R. H. Coupling (Consists of Two Pieces)
- 44. Brake Mounting Plate
- Disc Brake (See Separate Parts 45. List)
- 46. Retainer Ring
- 47. Drive Shaft
- Outer Bearing Retainer 48.
- 49. Retainer Ring
- 50. Roller Bearing
- 51. Retainer Ring
- 52. Retainer Ring 53. Locating Bearing
- 55. R. H. Bearing Housing
- 56. Flywheel Brake (Optional - See Separate Parts List)
- 57. Main Gear
- Outer Crankshaft Bushing 58.
- 59. Bushing Dowel
- 60. Inner Crankshaft Bushing
- 61. Crankshaft
- 2. Outer Bearing Cap
- Inner Bearing Cap á3.
- 64. Bearing Cap Stud
- Nut
- 66. Main Gear Key



739

