



## NIAGARA PIN CLUTCH PARTS

- 1—Latch Bracket
- 2—Latch Bracket Cover
- 3—Throwout
- 4—Clutch Pin
- 5—Locking Pin
- 6—Throwout Link

- 19—Clutch Pin Spring
- 20—Clutch Lever Stud

- 7—Shaft Collar
- 8—Spring Pin
- 9—Stop Pin
- 10—Washer for Clutch Lever Stud
- 11—Clutch Lever Pin
- 12—Spring Cup

- 13—Throwout Pin
- 14—Link Pin
- 15—Cap Screw for end of Shaft
- 16—Latch Bracket Spring
- 17—Shaft Collar Pin
- 18—Throwout Spring

- 21—Clutch Wheel with Striking Pins,  
Back-lash Pins and Bushing in place