

"B" TYPE CUSHION

1. Air Piping
(Furnished by Customer)
2. Bottom Cover Cap Screws
3. Mounting Plate
4. Cylinder Head Cap Screw
5. Bottom Cover
6. Guide Locknut
7. Locknut Set Screw
8. Oil Fitting
9. Lubrication Piping
10. Cylinder
11. "U" Packing
(Split for illustration purposes only)
12. Cylinder Guide Bushing
13. Cylinder Guide
14. Pressure Plate Screws
15. Pressure Plate
16. Cylinder Guide Mounting Screws
17. Cylinder Head

'B' TYPE CUSHION

