SLIDE ADJUSTMENT

60 Ton OBI



R-8205
Ref. Layout

1. Hex Nut, 1"-8
2. Knockout Rod
3. Sq.Hd.Set Scrw.
4. Jamb Nut
5. R.H. Gib
6. Knockout Bar
7. Hx.Hd.Cap Scrw.
8. Stud
9. Hex Nut,
10. Slide Cap
11. Roll Pin
12. L.H. Gib
13. Hx.Hd.Cap Scrw,
14. Hx.Hd.Cap Scrw,
15. Slide

INDICATOR ASSEMBLY

60 TON OBI



R-11746
Ref.Layout
C-94095

PARTS LIST FOR NEWER STYLE INDICATOR

1. Scale
2. Indicator Screw
3. Connection Nut (upper)
4. Connection Nut (lower)
5. Adjustment Lock Plate
6. Slide Adj. Lock Nut
7. Stud, 1"-14
8. Slotted Hex Nut
9. Pipe Plug, 0.25"
10. Dowel Pin, 7/16"x1-1/4"LG
11. Rack
12. Roll Pin, 3/32"x 3/4"LG
13. Adjustment Lock Cover
14. Spring
15. Knurled Nut
16. Gear Rack Holder
17. Dowel Pin, 1/8 x 1"LG
18. Soc.Hd.Cap Screws, 1/4-28 x 1/2"LG
    Connection Screw, New style
    Connection Screw, Old style



PARTS LIST FOR OLDER STYLE INDICATOR

1. Scale
2. Indicator Screw
3. Connection Nut
4. Adj. Lock Plate

R-8207
Ref.Layout

HEAD ASSEMBLY
60 Ton OBI



R-8203

1. Head
2. *Ecc.Bushing F.
3. Cam Limit Switch
4. Lock Sleeve
5. Ecc. Shaft
6. Front Cover
7. *Ecc. Bushing,
8. Connection
9. Retainer Ring
10. *Ecc.Bushing R.
11. *Oil Seal,
12. Main Gear
13. Shaft End Cover
14. Main Gear Key
15. Seal Housing

17. Gasket,

SLIDE ADJUSTMENT

60 Ton OBI



R-8205
Ref. Layout

1. Hex Nut, 1"-8
2. Knockout Rod
3. Sq.Hd.Set Scrw. 3/4-10"x 2"LG
4. Jamb Nut
5. R.H. Gib
6. Knockout Bar
7. Hx.Hd.Cap Scrw.
8. Stud
9. Hex Nut, 1"-14
10. Slide Cap
11. Roll Pin
12. L.H. Gib
13. Hx.Hd.Cap Scrw, 3/4-10"x4-1/2
14. Hx.Hd.Cap Scrw, 3/4-10"x2-1/4
15. Slide

INDICATOR ASSEMBLY

60 TON OBI



R-11746

PARTS LIST FOR **NEWER** STYLE INDICATOR

1. Scale
2. Indicator Screw
3. Connection Nut (upper)
4. Connection Nut (lower)
5. Adjustment Lock Plate
6. Slide Adj. Lock Nut
7. Stud, 1"-14
8. Slotted Hex Nut
9. Pipe Plug, 0.25"
10. Dowel Pin, 7/16"x1-1/4"LG
11. Rack
12. Roll Pin, 3/32"x 3/4"LG
13. Adjustment Lock Cover
14. Spring
15. Knurled Nut
16. Gear Rack Holder
17. Dowel Pin, 1/8 x 1"LG
18. Soc.Hd.Cap Screws, 1/4-28 x 1/2"LG

Connection Screw, New style

Connection Screw, Old style



PARTS LIST FOR **OLDER** STYLE INDICATOR

1. Scale
2. Indicator Screw
3. Connection Nut
4. Adj. Lock Plate

R-8207
Ref.Layout



R8206

CLEARELEASE MECHANISM

60 Ton OBI

1. Wrist Pin
2. Locking Nut
3. Wrist Pin Bushing
4. Locating Dowel

COUNTER BALANCE

60 Ton OBI



R-11744

1. Hex Nut
2. Tie Rod
3. Locknut
4. Steel Washer
5. Piston
6.* 'U'-Cup Packing
7. Hx.Hd.Cap Scrw.
8. Counterbal. Shaft
9. Roll Pin
10. Cotter Pin (2)
11. Screw Eye
12. Spring Pin
13. Clevis Pin
14. Clevis
15. Cylinder Head
16. Cylinder - Inner
17. Cylinder - Outer
18.* 'U'-Cup Packing
19. Felt Wiper, style 8501
20.* Gasket, 8"x4"x 1/16"
21.* Gasket, 8"x4"x 1/16"
22. Cylinder Cover

HEAD ASSEMBLY
60 Ton OBI



R-8203

1. Head
2. *Ecc.Bushing F.
3. Cam Limit Switch
4. Lock Sleeve
5. Ecc. Shaft
6. Front Cover
7. *Ecc. Bushing,
8. Connection
9. Retainer Ring
10. *Ecc.Bushing R.
11. *Oil Seal,
12. Main Gear
13. Shaft End Cover
14. Main Gear Key
15. Seal Housing
17. Gasket,

MOTOR DRIVE

60 Ton OBI



R-8204

1.* Vbelts
2. Hx.Hd.Cap Scrws
3. Security Locknut
4. 10 HP Main Motor
5. Sheave
6. Cotter Pins
7. Hx.Hd.Cap Scrws
8. Bracket
9. Washers
10. Motor Support Pin
11. 10 hp Motor Support
12. Pivot Pin
13. Rod End
14. Hex. Nut
15. Spacers (2)
16. Yoke
17. Pin
18. Cotter Pins