SUGGESTED INSPECTION & MAINTENANCE RECORD



Company		Address			
Press Equipment No.		Location			
Press Model	Make	S	Serial No.		
Tonnage	Installation Date		Aux Equip: Feed	Scrap Shear	
Reel	Cradle	Straightener	Other		
Type of Point of Opera	tion guarding:				

	Increation					
	inspection interval	ок	Date	Maintenance Required	Date Repaired	Shop Order No.
FRAME CONDITION						
Members solid	М					
Bed Level	3M					
Tie rods secure	М					
Brackets/Components Secure	w					
LEGS (OBI)						
Solid	М					
Secure to frame	М					
Bolted to floor	м		TOTAL			
POINT OF OPERATION						
Guards in place & secure	D		***************************************		***************************************	
Adjusted properly	D		***************************************			
Devices being used properly	D					
Devices adjusted properly	D					
Hand tools used (if req'd.)	D					***************************************
KNOCKOUT BAR						
Proper adjustment	D					
Brackets secure	D					
Adjusting screws straight	D					
Bar straight	D					
Brackets secure	D					
AIR PRESSURE SETTING						
Proper air pressure - Clutch, Ctr. Bal., Other (specify)	D					449
COVERS						
Flywheel - In place & secure	М		***************************************			
Gear - In place & secure	М					
Clutch - In place & secure	м				· · · · · · · · · · · · · · · · · · ·	
Brake – In place & secure	м					
Feed & scrap shear in place	w					
Others - In place & secure	М					
FULL ROTATION CLUTCH						
Engage & disengage properly	w					
Fripping mech. Shielded	W					
Proper lubrication	D					

Notes: D = DAILY, W = WEEKLY, M = EVERY MONTH, 3M = EVERY THREE MONTHS, 6M = EVERY SIX MONTHS

SUGGESTED INSPECTION & MAINTENANCE RECORD



	Inspection Interval	ок	Date	Maintenance Required	Date Repaired	Shop Order No.
AIR CLUTCH				•		
Engage & disengage properly	w					
Proper lining wear	w					
Proper air pressure	D					
Airline filter clean	D					
Clutch properly lubricated	D					
Air swivel properly lubricated	3M		* * * * * * * * * * * * * * * * * * * *			
BRAKE						
Proper lining wear	w					
Properly adjusted	D					
Proper air pressure	D				. 2400	
CONTROLS			***************************************			
Functioning properly	w					
Controls being used properly	D					
Set properly for operation	D					
All electrical covers in place	м		····			
All wire protected	м					
Proper fusing & thermal units	3M	<u> </u>				
Air pres. Switches properly set	3M					***************************************
LUBRICATION						
Lubrication functioning prop.	р					
Press lubed properly (visual)	D					***************************************
Proper oil level in slide adj.	D					
Oil or grease in reservoir	D					
Lines and fittings intact	D					
BEARINGS						· · · · · · · · · · · · · · · · · · ·
Main – clearance	6M					
Connection – clearance	6M					
Wrist or ball – clearance	6M					Western America
Total clearance of slide assy.	6M					
Antifriction – properly lubricated	6M					
Antifriction – properly fit	6M					
SLIDE						
Record parallelism	6M					THE PERSON NAMED IN COLUMN NAM
Record gib clearances	6M					
Even gib wear	М					
Slide flange secure	M					
Slide adj. Functioning properly	М					
SLIDE COUNTERBALANCE	w					
(Spring Type) intact	w					
Properly adjusted	w					
(Air Type) intact	w					
Proper air. Pressure for job	D					
Proper lubrication	D					The second secon
Surge tanks drained	D		***************************************			

Notes: D = DAILY, W = WEEKLY, M = EVERY MONTH, 3M = EVERY THREE MONTHS, 6M = EVERY SIX MONTHS

SUGGESTED INSPECTION & MAINTENANCE RECORD



	Inspection Interval	ок	Date	Maintenance Required	Date Repaired	Shop Order No.
GEARS						
Proper lubrication	w					
Even wear	6M					
Driveshaft & crank, straight	6M					
Proper fit on shaft	6M					
Teeth intact	6M					
Record backlash	6M					
FLYWHEEL/SHEAVE/BELTS		·	**************************************			
Flywheel secure on shaft	М		***************************************			
Sheave grooves aligned with flywheel grooves	3M					·
Belt wear	3M					
Proper belt tension	3M					
MOTORS						
Secured to bracket						2000
Bracket secure to press	М					
Motor brkt. hinge pin wear	м				·	***************************************
Adjusting mechanism secure	М					
Restraining cable secure	М					
Wires protected	М					
OVERLOAD						
Press appears overloaded?	М					ANNUAL TEACH TO THE TOTAL TO THE TOTAL TO THE TOTAL TEACHER THE TOTAL
Further inspection required	D					
AIR BLOW OFF						***************************************
Hoses & fittings	D					
Proper adjustment	D				71111	
PNEUMATIC CUSHION					310000	
Air controls adjusted properly	D					· · · · · · · · · · · · · · · · · · ·
Lines & fittings	М					
CLEAR OF SCRAP/DEBRIS			•			
Well lighted	D		•			
Oil splatter	D					
Noise level	D					

Notes: D = DAILY, W = WEEKLY, M = EVERY MONTH, 3M = EVERY THREE MONTHS, 6M = EVERY SIX MONTHS

Inspection performed by:	
Date:	
A complete file of Engineering and Manufacturing records, technical data, and other special information pertaining to your Bliss Clearing N press is kept in our files.	Niagara
If at any time you need further assistance, please contact our Service Department or our Repair Parts Department. Our qualified Field Se Technicians are also available to you upon request.	rvice

Bliss Clearing Niagara, Inc. 1004 E. State Street

Toll Free: 800-642-5477 Telephone: 269-948-3300

info@bcntechserv.com

Hastings, MI 49058

Fax: 269-948-3313



The Right Part...Right Now!

FOUNDATIONS

It is impractical for us as a machine manufacturer to make recommendations on thickness of foundation walls, foundation floors, or foundation footings because of the great variation of soil conditions at the point of installation of our equipment.

Another reason for not making specific recommendations is the great variation in type of concrete mixes and the variation in uses of concrete reinforcing.

As a guide for your general use, however, the table shown here gives a general classification of soils and the safe pressure which they may support. These values approximate the pressures allowed by the building law in most cities.

If there is any question relative to thickness of foundations, types of reinforcing, etc., we would suggest that you consult a local contractor who is acquainted with soil conditions in your locality.

SAFE BEARING IN SOILS

	Safe Bearing Capacity, Tons Square Foot	
NATURE OF SOIL:		
Solid ledge of hard rock, such as granite, trap, etc	•	25 - 100
Sound shale and other medium rock, requiring blasting for removal	•	10 - 15
Hardpan, cemented sand & gavel, difficult to remove by picking		. 8 – 10
Soft rock, disintegrated ledge; in natural ledge, difficult to remove by	picking	5 – 10
Compact sand and gravel, requiring picking for removal .	•	5 – 6
Hard clay, requiring picking for removal		4 - 5
Gravel, coarse sand, in natural thick beds	•	4 - 5
Loose medium and coarse sand, fine compact sand		3 - 4
Medium clay, stiff but capable of being spaded	•	2 - 4
Fine loose sand	•	1 - 2
Soft clay.		1

2 x Press Weight = Dynamic load Dynamic load has to be spread over feet areas.

GENERAL FOUNDATION SPECIFICATIONS

As a general guide, the following should be used in determining a foundation:

- A. If the soil on which the foundation is to be poured is of a hard clay type, the bearing capacity of that soil is approximately 4 to 5 tons per square foot.
- B. The foundation should consist of reinforced concrete, rigid enough to support the press weight plus an allowance of approximately 100% to compensate for the dynamic forces of blanking. This condition requires that condition A (above) is met or exceeded.
- C. It is suggested that a local contractor who is familiar with the area soil conditions be consulted.
- D. For best results, the press should be mounted on an isolated inertial block so that vibrations are reduced to the surrounding building and equipment. The size of the inertia block is determined using conditions A, B and C from above. It is suggested that the inertia block be separated from the surrounding floor by at least one inch of material such as insulation board or material which will give and take such things as vibration and expansion from temperature change.
- E. Special care should be taken to provide a smooth, level mounting surface. Concrete alone does not usually provide a good enough surface. One method of providing an accurate mounting surface is to set a steel mounting plate into the concrete when the foundation is poured. Anchor bolts to fix the press to the foundation also be cast into the foundation.
- F. The foundation should also be located away from the building foundation and any ceiling supports by a distance of approximately 8 to 10 feet.

Bliss Clearing Niagara, Inc. Toll Free: 800-642-5477
1004 E State Street Telephone: 269-948-3300
Hastings, MI 49058 Fax: 269-948-3313